

User Manual

Cold Room Controller

CRC 1200



www.subzero.co



Index		
PARAMETER	DESCRIPTION	Pg. No.
	Introduction	3
	Get to Know Your Controller	4
	Key Introduction	5
	Main Programming Mode	5
	Parameter List	5
SET POINT	To set the cut-out point of the controller.	5
MAX SET POINT	To set the Maximum System Cooling temperature.	6
MIN SET POINT	To set the Minimum Cooling Temperature.	6
DIFFERENTIAL	To set the differential for Compressor restart.	7
QUICK FREEZE SP	To set Quick Freeze Set Point.	7
QUICK FREEZE DUR	To set Quick Freeze Duration.	7
ROOM PROBE CAL	To set Room Probe 1 calibration.	8
COMP TIME DELAY	To set time delay between compressors relay restart time.	8
DRIP TIME DUR	To set drip time for defrost water.	9
POST DRIP TIMING	To set Post Drip Timings.	9
COMP ON PRB.FAIL	To set compressor function during Room probe failure.	9
CONDENSOR ON DLY	To Set Condensor On Delay Timings.	9
EVAP FAN STOP TC	To set Evaporator Fan Stop Temperature.	10
EVAP TIME DELAY	To set Evaporator Restart Time Delay.	10
EVAP Wn COMP OFF	To set Evap Fan operation when compressor is off.	10

Index		
PARAMETER	DESCRIPTION	Pg. No.
EVAP DIFFERENTIAL	To set Evaporator Differential.	10
COIL PROBE CAL.	To set coil probe calibration.	11
EVAP At DEFROST	To set Evap. Fan status during defrost.	11
EVAP At DOOR Open	To set Evap. Fan status during Door open condition	11
DEFROST TYPE	To set type of defrost.	11
DEFROST COMPUTING	To set type of computation for defrost time.	12
DEFROSTFREQUENCY	To Set Defrost frequency.	12
DEFROST DURATION	To set Maximum Defrost duration.	12
DEFROST STOP TEMPERATURE	To set final defrost temperature. (Coil probe).	13
POWER ON DEFROST	To activate power ON Defrost.	13
DEFROST DURATION IN COIL PRB. FAIL	To set Defrost duration IN Coil probe Failure.	13
PUMP DOWN	To activate Solenoid Valve Relay.	14
KEYPAD LOCK	To activate Keypad Lock.	14
FACTORY RESET	To revert to Factory Parameters.	14
SAVE PROGRAMMING	To Save programming.	14
	Technical Data	15
	Technical Data	16
	Wiring Diagram	17
	Caution & Warranty	18

Introduction

The CRC-1200 is a panel/wall mounted controller dedicated to controlling the cold room and its various devices.

Features:

The controller controls the defrost in the system based on either an electrical heater where the compressor is stopped, or at cycle inversion using warm gas where the compressor keeps on working.


It is also possible to select the interval between defrosts and a maximum time out after which the defrost is interrupted. The same probe which controls the defrost cycle is also used to control the evaporator fans. Post drip and condensor fan control are amongst many other features in this controller.

There are safety features which include shutting down the system incase of a fault from a pressure control or similar device.

Computer Connectivity over RS485 and Remote monitoring(Optional).












Single Operation Quick Freeze Mode(Press UP Key for 4 sec), Set system in quick freeze mode which is time based for that period new setpoint will be lower than running setpoint and system will try to achieve that setpoint, after time period over set point will be normal setpoint.

Get to Know Your Controller



Items included

NO.	ITEMS	QTY
1.	CONTROLLER	1
2.	SENSOR 3 METER	1
3.	SENSOR 5 METER	1
4.	CATALOGUE	1
5.	6 X 25 SCREW	3

Key Introduction			
	Lamp ON/OFF Key		Up Key / Quick Freeze / Hold & Release LCD Messages
	Auxiliary Key (unused)		Clock/Down Key
	Alarm Reset Key		Set Key
	Defrost Key		Power Key
	Program Key		Quick Freeze
MAIN SYSTEM PROGRAMMING MODE			
1> USER PROGRAM		Press SET Key to Enter Programming mode.	
2> TIME SETTINGS		Press SET Key to Enter in Time settings.	
3> FAULT LOG		Press SET Key to View last 10 Fault Log.	
4> CLEAR FAULT LOG		Press SET Key to clear last Fault Log.	
5> COPY FROM PGM KEY		Insert HOT Key and Press SET Key to program System using external Program Key.	
5> DEVICE ID 1-64		Press SET Key to Change Device ID.	
7> EXIT PROGRAMMING		Press SET Key to Exit Programming Mode.	
Min: MINIMUM Max : MAXIMUM Fact. Set : FACTORY SETTING(DEFAULT)			
Description of parameters and functions.			
Sr. No.	Parameter (LCD Message)	Parameter setting method	
01	SET POINT	To set the cut-out point of the controller.	
Press and hold SET key for 4 seconds and Release.			Display will change to set value. The set point value can now be changed by using the UP/DOWN key. After desired value, press the SET key & you will see "---" which confirms that the set point has been stored in memory.
Range			
Min	Max		Fact. Set
-20°C	35°C		-15°C

Description of parameters and functions.				
Sr. No.	Parameter (LCD Message)	Parameter setting method		
To set other parameter				
Press & hold PRG key for 4 seconds <div>PRG</div>		Display will show "SELECT MODE 1 > USER PROGRAM MODE" Press SET key display will show set point. To go other parameter, use UP/DOWN keys.		
02	MAX SET POINT	Function: To set the Maximum System Cooling Temperature		
To change Max Set Point parameter, press the set key.		Use UP/DOWN key to set desired value. Once set at a particular value, this will not allow set points to go above this value and below QUICK FREEZE SP setting.		
Range		Example : Setting this parameter at 30°C if the temperature reaches 30°C, this is the Ht (High Temperature) condition but at power on till 20minutes controller will not generate HT Alarm.		
Min	Max			Fact. Set
SP	35°C			35°C
03	MIN SET POINT	Function: To set the Minimum Cooling Temperature.		
To change Min Set Point parameter, press the set key.		Use UP/DOWN key to set desired value. Once set at a particular value, this will not allow set points to go above this value and below QUICK FREEZE SP setting.		
Range		Example : Setting this parameter at -30°C will not allow the set point to go below -30°C. Also, if temperature reaches -30°C, the display will show Low Temp. Alarm indicating that the temperature has gone below the value in this parameter and at this point the alarm will come on.		
Min	Max			Fact. Set
-50°C	QFSP			-50°C
QFSP - QUICK FREEZE SP				

Description of parameters and functions.			
Sr. No.	Parameter (LCD Message)		Parameter setting method
04	DIFFERENTIAL		Function: To set the differential for compressor restart.
To change DIFFERENTIAL parameter, press the set key.			Use UP/DOWN keys to set desired value.
Range			Example : If setpoint is set at 10°C and differential is set at 2°C, then when the system reaches 10°C, the compressor relay will cutout and since the differential is 2°C, the relay will cutin (restart) at 12°C (10°C + 2°C).
Min	Max	Fact. Set	
1°C	20°C	2°C	
05	QUICK FREEZE SP		Function: To set Quick Freeze Set Point.
To change Quick Freeze SP parameter, press the set key.			Use UP/DOWN keys to set desired value. This Parameter will set QUICK Freeze Set Point during QUICK Freezing Defrost will not occur.
Range			Example : If this set to -20°C, and quick freeze frequency is set to 1 hr ,then when it is set to quick freeze mode, then the Comp. will take -20°C set point for 1 hr.
Min	Max	Fact. Set	
-50°C	SP	-20°C	
06	QUICK FREEZE DUR		Function: To set Quick Freeze Duration.
To change Quick Freeze Dur parameter, press the set key.			Use UP/DOWN keys to set desired value. This is the maximum amount of time allowed for Quick Freeze. If set to "0", there will be no quick freeze.
Range			Example : see QUICK FREEZE SP parameter.
Min	Max	Fact. Set	
0Hrs	12 Hrs	0 Hrs	

Description of parameters and functions.				
Sr. No.	Parameter (LCD Message)	Parameter setting method		
07	ROOM PROBE CAL	Function: To set room probe 1 calibration.		
To change the Room Probe Cal parameter, press the set key.		Use UP/DOWN keys to set desired value.		
Range		In time it may be possible that the display may be offset by a degree or so. To compensate for this error, you may need to add or minus the degrees required to achieve the correct temperature. Setting value is from -10°C to + 10°C.		
Min	Max			Fact. Set
-10°C	10°C	0°C	Example : The temperature on the display is 28°C, whereas the actual temperature is 30°C. You will need to set the Calib. Val to 2, which means that once out of the programming mode, the temperature will show 30°C (28°C + 2°C).	
08	COMP TIME DELAY	Function: To set time delay between compressors relay restart time.		
To change the Comp Time Delay parameter, press the set key.		Use UP/DOWN keys to set desired value.		
Range		This parameter is used to protect the compressor from restarting in a short period of time and can be set between 0 to 20 minutes.		
Min	Max	Fact. Set	Example : If this parameter is set at 3 minutes, the relay will cut off at the set temperature, but will not restart for a minimum of 3 minutes, even if the differential is achieved earlier. This parameter is good to protect the life of the compressor or even in applications where the probe is placed at places where there are sudden & short changes in temperature .	
0 Min	20 Min	3 Min		

Description of parameters and functions.			
Sr. No.	Parameter (LCD Message)	Parameter setting method	
09	DRIP TIME DUR	Function: To set drip time for defrost water.	
To change the Drip Time Dur parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0 Min	30 Min	1 Min	
10	POST DRIP TIMING	Function: To set Post Drip Timings.	
To change the Post Drip Timing parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
15 Sec	99 Sec	30 Sec	
11	COMP ON PROBE FAIL	Function: To set Compressor function during room probe failure.	
To set compressor function during room probe failure.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0	2	1	
12	CONDENSER ON DLY	Function: To Set Condensor On Delay Timings..	
To change the Condenser On Dly parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0 Sec	30 Sec	15 Sec	

Description of parameters and functions.			
Sr. No.	Parameter (LCD Message)	Parameter setting method	
13	EVAP FAN STOP TC	Function: To set Evaporator Fan Stop Temperature.	
To change Evap Fan Stop Tc parameter, press the set key.		Use UP/DOWN keys to set desired value. This setting is used to limit the max. temperature beyond which the Evap. Fan will cut off.	
Range			
Min	Max	Fact. Set	
-40°C	35°C	2°C	
Example : If this parameter is set to 2°C, then Evap. Fan will cut off at 2°C.			
14	EVAP TIME DELAY	Function: To set Evaporator Restart Time Delay.	
To change Evap Time Delay parameter, press the set key.		Example :If this is set at 3 minutes, the Evap. Fan relay will cut off at the temp. set by Evap. Fan Stop TC. parameter but the Fan will not come on for a minimum of 3 minutes even if it's differential is achieved earlier.	
Range			
Min	Max	Fact. Set	
0 Min	20 Min	1 Min	
15	EVAP Wn COMP OFF	Function : To set Evap Fan operation when compressor is off	
To change Evap Wn Comp Off parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0	1	1	
16	EVAP DIFFERENTIAL	Function : To set Evaporator Differential.	
To change Evap Differential parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
1°C	20°C	2°C	
Example:If Evap Fan Stop Tc parameter is set to 2°C, and if EVAP DIFFERENTIAL parameter is set to 2°C, then Evap. Fan will cut off at 2°C and restart only at 0°C(2°C-2°C = 0°C).			

Description of parameters and functions.			
Sr. No.	Parameter (LCD Message)	Parameter setting method	
17	COIL PROBE CAL.	Function: To set coil probe calibration.	
To change Coil Probe Cal. parameter, press the set key.		Use UP/DOWN keys to set desired value.	
		In time it may be possible that the display may be offset by a degree or so. To compensate for this error, you may need to add or minus the degrees required to achieve the correct temperature. Setting value is from -10°C to + 10°C	
Range			
Min	Max	Fact. Set	
-10°C	10°C	0°C	
18	EVAP At DEFROST	Function: To set Evap. Fan status during defrost.	
To change Evap At Defrost parameter, press the set key.		Use UP/DOWN keys to set desired value.	
		0 = Evaporator Fan will stay OFF during defrost. 1 = Evaporator Fan will stay ON during defrost.	
Range			
Min	Max	Fact. Set	
0	1	0	
19	EVAP At DOOR OPEN	Function : Evap fan status during door open condition.	
To change Evap at Door Open parameter, press the set key.		Use UP/DOWN keys to set desired value.	
		0 = ON 1 = OFF	
Range			
Min	Max	Fact. Set	
0	1	0	
20	DEFROST TYPE	Function : To set type of defrost.	
To change Defrost Type parameter, press the set key.		Use UP/DOWN keys to set desired value.	
		0 = Heater defrost in which case Compressor is OFF. 1 = Hot gas defrost where Compressor is ON.	
Range			
Min	Max	Fact. Set	
0	1	0	

Description of parameters and functions.			
Sr. No.	Parameter (LCD Message)	Parameter setting method	
21	DEFROST COMPUTING	Function: To set type of computation for defrost time.	
To change Defrost Computing parameter, press the set key.		Use UP/DOWN keys to set desired value.	
		0 = Total of real time. Example : This means that the time calculation for defrost frequency will be for the total hours the unit has been running.	
		1 - Sum of total compressor operating times. This means that for time calculation, the unit will add the total time the compressor has been in an ON mode. It keeps a record of the hours worked +/-1 Hour incase of a power failure. Example : If Defrost frequency is set to 6 hrs. and 3 ½ hrs have passed after unit has started and power fails, then defrost cycle will stat after 3 hours when power resumes.	
Range			
Min	Max	Fact. Set	
0	1	0	
22	DEFROST FREQUENCY	Function: To Set Defrost frequency.	
To change Defrost Frequency parameter, press the set key.		Use UP/DOWN keys to set desired value.	
		This is the amount of time between two defrost cycles.	
Range			
Min	Max	Fact. Set	
1 Hrs	12 Hrs	4 Hrs	
23	DEFROST DURATION	Function: To set Maximum Defrost duration.	
To change Defrost Duration parameter, press the set key.		Use UP/DOWN keys to set desired value.	
		This is the maximum amount of time allowed for a defrost. If set to 0, there will be no defrost cycle.	

Description of parameters and functions.			
Sr. No.	Parameter (LCD Message)	Parameter setting method	
Range		Example : If this parameter is set to 15 minutes, and Defrost frequency parameter is set at 1 hr. Then '1 hr' after power is applied to the controller, defrosting for 15 minutes will take place. This cycle will repeat every '1 hr'.	
Min	Max		
0 Min	45 Min		
24	DEFROST STOP TEMPERATURE	Function: Final defrost temperature. (Coil probe). To change Defrost stop temperature parameter, press the set key.	
Range		Example :If this parameter is set to 7°C, then if defrosting is in progress then when DEFROST STOP TEMPERATURE temperature reaches 7°C, the defrost process will stop.	
Min	Max		
0°C	15°C		
25	POWER ON DEFROST	Function: To activate power ON Defrost. To change Power ON Defrost parameter, press the set key.	
Range		This also depend on Coil Temperature 0 = No Power Up Defrost 1 = Power Up Defrost	
Min	Max		
0	1		
26	DEFROST DURATION IN COIL PRB.FAIL	Function: To set Defrost duration IN Coil probe Failure. To change Defrost Duration IN Coil PRB. Fail parameter, press the set key.	
Range		Example : If this is set to 5 minutes, then Manual defrost for 5 minutes will take place during Coil probe fail.	
Min	Max		
1Min	10 Min		

Description of parameters and functions.			
Sr. No.	Parameter (LCD Message)	Parameter setting method	
27	PUMP DOWN	Function: To activate Solenoid Valve Relay. To change Pump Down parameter, press the set key.	
Range		Use UP/DOWN keys to set desired value. 0 = SV relay will not activate. 1 = SV relay will get activated and will cut out and cut-in according to set temperature.	
Min	Max		
0	1		
28	KEYPAD LOCK	Function: To activate Keypad Lock. To change Keypad Lock parameter, press the set key.	
Range		This parameter can lock the keypad so that tempering is not possible by bystanders. 0 - deactivates keypad lock. 1 - activates keypad lock. This parameter can lock the keypad so that tempering is not possible by bystanders. When locked all parameters can only be viewed, but not modified.	
Min	Max		
0	1		
29	FACTORY RESET	Function: Revert to Factory Parameters. To change Factory Reset parameter, press the set key.	
Range		Use UP/DOWN keys to set desired value. 1=Revert to factory set parameters. If we set this parameter 1 and press set Key then all factory default parameter will get loaded.	
Min	Max		
0	1		
30	SAVE PROGRAMMING	Function: To save system programming parameters. To change Save Programming parameter, press the set key.	
		Use UP/DOWN keys to set desired value. 1> Send To External Key. 2> Exit Programming.	

Technical Data

Power supply

Controller Input Supply : 230VAC, +/-15%, 50Hz

Digital Inputs

Digital Inputs : 4Nos.

Digital Input type : 230 VAC, 3Nos.

Potential Free Contacts 1Nos.

Input Nomenclature :

- 1) SPPR Input
- 2) High pressure input from compressor
- 3) Low pressure input from compressor
- 4) Door Input(Potential Free Contacts Input)

Sensors

1)Temperature Sensor: (Room temperature & Coil temperature)

Sensor Type: NTC Thermistor

Resolution : +/-1deg.C

Accuracy : +/-1deg.C

Range : -50°C to 35°C.

Digital Outputs

Digital Outputs : 7

Type : Relay

Sr. No	Output Nomenclature	Output Contact Rating	Contact Arrangement
1	Compressor	8(3)A/250VAC (Inductive)	C, NO
2	Condenser Fan	8(3)A/250VAC (Inductive)	NO
3	Evaporator Fan	8(3)A/250VAC (Inductive)	NO
4	Pump Down	8(3)A/250VAC (Inductive)	NO
5	Defrost Heater	8(3)A/250VAC (Inductive)	NO
6	Panel Lamp	8(3)A/250VAC (Inductive)	NO
7	Alarm	8(3)A/250VAC (Inductive)	C, NO, NC

Technical Data

User Interface

Display : 2 Digit Seven Segment Display (Red)
(1.00" and 8 LEDs for indication.)

16X2 LCD Display For System Status

Keypad : 9 keys (may change)

Rs485 Connectivity : Modbus RTD Protocol

Baud Rate : 9600, N, 8, 1

Device ID : 1 (By Default)

Hot Key(Optional)

Housing

Material : ABS plastic.

Front cover : Polycarbonate plastic.


Dimensions : Length 227mm, Width 200mm, Depth 93 mm

Mounting : Panel/Wall mounting with screws.

Key Features:

- PC Connectivity Using Modbus RTU Open Protocols over RS485 and can be Interfaced with any BMS system which supports Modbus RTU Protocols.
- Remote monitoring and control using GUI Software (optional).
- Inbuilt RTC.
- QUICK Freeze Mode.
- Evaporator Fan Control based on Coil temperature.
- Door Input (Potential Free Contacts).
- Last 10 Fault Logs.
- LCD Display to show System Status and as user guide while programming.
- Time Based Defrost Cycle
- Manual Defrost Key
- Power Switch Key.
- Software Precaution to avoid multiple Defrost
- Additional Condenser Fan Relay
- Hot Key for programming (optional).
- Post Drip function after defrost cycle
- Software enabled power up defrost cycle
- Real time computing for Defrost cycle timing.

Suggested wiring Diagram



Controller

Controller should be installed in a place protected by vibration, water and corrosive gasses and where ambient temperature does not exceed the values specified in the technical data.

Probe	

To give a correct reading, the probe must be installed in a place protected from thermal influences, which may affect the temperature to be controlled.

Caution

WIRING : The probe and its corresponding wires should never be installed in a conduit next to control or power supply lines. The electrical wiring should be done as shown in the diagram. The power supply circuit should be connected to a protection switch. The terminals admit wires of upto 2.5sq mm.

WARNING : Improper wiring may cause irreparable damage and personal injury. Kindly ensure that wiring is done by qualified personnel only.

Maintenance : Cleaning : Clean the surface of the controller with a soft moist cloth. Do not use abrasive detergents, petrol, alcohol or solvents.

Notice

The information in this document is subject to change in order to improve reliability, design or function without prior notice and does not represent a commitment on the part of the company. In no event will the company be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company.

Disclaimer

This manual & its contents remain the sole property of A.S.Controls Pvt.Ltd., India and shall not be reproduced or distributed without authorization. Although great care has been taken in the preparations of this document, the company or its vendors in no event will be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company. A.S.Controls Pvt.Ltd. reserves the right to make and changes or improvements without prior notice.

Warranty

This product is warranted against defects in materials and workmanship for a period of one year from the date of purchase. During the warranty period, product determined by us to be defective in form or function will be repaired or, at our option, replaced at no charge. This warranty does not apply if the product has been damaged by accident, abuse, and misuse or as a result of service or modification other than by the company. This warranty is in lieu of any other warranty expressed or implied. In no event shall the company be held liable for incidental or consequential damages, such as lost revenue or lost business opportunity arising from the purchase of this product.

OUR OTHER PRODUCTS



INDIA

Cold Room Controller

Chiller Controller

Two Compressors Controller

Heating Controller

Humidity Controller

Pressure Controller



Ball Valves

Globe Valves

Hand Valves

Flow Switches

Solenoid Valves